



BCKNR/L



Обозначение	Размеры					Пластина	Подкл. пластина	Винт	Прижим	Винт	Кольцо	Ключ	
	A	B	L	E	F								
BCKNR/L2020K12	20	20	125	33	24	CN**1204	MC1204	CTM6-S	BC12-100	BCS08	CR07	L3.0 L4.0	
BCKNR/L2525M12	25	25	150	32	32								
BCKNR//L3232P12	32	32	170	32	40								



Обозначение	Размеры							Пластина	Подкл. пластина	Винт	Прижим	Винт	Кольцо	Ключ	
	Ø D	Ø d	H	L	S	ℓ	a°								
S32S-BCKNR/L12	40	32	30	250	22	50	17°	CN**1204	BC12-100	CTM6-S	MC1204	BCS08	CR07	L3.0 L4.0	
S40T-BCKNR/L12	50	40	38	300	27	50	15°								
S50U-BCKNR/L12	63	50	48	350	31	50	12°								