


## PCKNR/L



Обозначение	Размеры						Пластина	Подкл. пластина	Рычаг	Винт	Скоба	Ключ
	H	W	L	l	h	s						
PCKNR/L1616H12	16	16	100	27	16	20	CN**1204	SC42	LV4	VHX0821	SP4	L3.0
PCKNR/L2020K12	20	20	125	27	20	25						
PCKNR/L2525M12	25	25	150	30	25	32						
PCKNR/L2525M16	25	25	150	33	25	32	CN**1606	SC53	LV5	VHX0825	SP5	
PCKNR/L3232P16	32	32	170	33	32	40						
PCKNR/L3232P19	32	32	170	38	32	32	CN**1906	SC63N	LV6N	VHX1027N	SP6N	

