


PSSNR/L



Обозначение	Размеры						Пластина					
	H	W	L	l	h	s		Подкл. пластина	Рычаг	Винт	Скоба	Ключ
PSSNR/L2020K12	20	20	125	34	20	25	SN**1204	SS42	LV4	VHX0821	SP4	L3.0
PSSNR/L2525M12	25	25	150	34	25	32						
PSSNR/L3232P12	32	32	170	34	32	40						
PSSNR/L2525M15	25	25	150	36	25	32	SN**1506	SS53	LV5	VHX0825	SP5	
PSSNR/L3232P15	32	32	170	36	32	40						
PSSNR/L3232P19	32	32	170	43	32	40	SN**1906	SS63N	LV6N	VHX1027N	SP6N	

