


SER/L



Обозначение	Размеры						Пластина	Подкл. пластина	Винт	Винт	Ключ
	H	W	L	S	h	l					
SER/L1212F11	12	12	80	14	12	15	11ER/L**	X	M2.5*8	X	T8
SER/L1212F16	12	12	80	16	12	22			M3.5*9		
SER/L1616H16	16	16	100	20	16	22	16ER/L**	STM16	M3.5*12	M3*6N	T15
SER/L2020K16	20	20	125	25	20	27					
SER/L2525M16	25	25	150	32	25	30					
SER/L3232P16	32	32	170	40	32	32					
SER/L2525M22	25	25	150	32	25	31	22ER/L**	STM22R	M4*16	M4*6N	T20
SER/L3232P22	32	32	170	40	32	31		STM22L			
SER/L4040R22	40	40	200	50	40	31	27ER/L**	STM27	M5*20		
SER/L3232P27	32	32	170	40	32	33,5					
SER/L4040R27	40	40	200	50	40	33,5					

