


SMBB



Обозначение	Размеры									Лезвие	 Ключ
	H	W	H3	L	H1	H2	W1	B	M		
SMBB1626	16	13	26	86	43	13	32	5,3	3-M6	SPB*** ^(S)	L5.0
SMBB2026	20	19	26	86	43	9	38	5,3			
SMBB2032	20	19	32	100	50	13	38	5,3	4-M6		
SMBB2526	25	23	26	86	43	4	42	5,3	3-M6		
SMBB2532	25	23	32	110	50	8	42	5,3	4-M6		
SMBB3232	32	30	32	110	54	5	48	5,3			