


T90-SC



Обозначение	Склад	Размеры					Режущая пластина	Винт	Ключ
		D	A	Z	d	Ap			
T90-D80-27-10-11-8-SC	●	80	10	8	27	11	SCMT09T3	TC079 M4x11	T15
T90-D100-32-10-24-8-SC	●	100	10	8	32	24			
T90-D125-40-10-32-10-SC	●	125	10	10	40	32			
T90-D160-40-10-50-12-SC	●	160	10	12	40	50			
T90-D200-40-10-65-14-SC	●	200	10	14	40	65			
T90-D80-27-12-11-8-SC	●	80	12	8	27	11			
T90-D100-32-12-24-8-SC	●	100	12	8	32	24			
T90-D125-40-12-32-10-SC	●	125	12	10	40	32			
T90-D160-40-12-50-12-SC	●	160	12	12	40	50			
T90-D200-40-12-65-14-SC	●	200	12	14	40	65			
T90-D80-27-16-11-8-SC	●	80	16	8	27	11	SCMT1204	TC083 M5x12	T20
T90-D100-32-16-24-8-SC	●	100	16	8	32	24			
T90-D125-40-16-32-10-SC	●	125	16	10	40	32			
T90-D160-40-16-50-12-SC	●	160	16	12	40	50			
T90-D200-40-16-65-14-SC	●	200	16	14	40	65			
T90-D125-40-20-32-10-SC	●	125	20	10	40	32			
T90-D160-40-20-50-12-SC	●	160	20	12	40	50			

