



## SVJBR/L






Обозначение	Размеры						Пластина	 Винт	 Ключ
	H	W	L	l	h	s			
SVJBR/L1212F11	12	12	80	22	12	16	VB**1103	M2.5*8	T8
SVJBR/L1616H11	16	16	100	25	16	20			
SVJBR/L2020K11	20	20	125	32	20	25			
SVJBR/L2525M11	25	25	150	38	25	32			
SVJBR/L1616H16	16	16	100	30	16	20	VB**1604	M3.5*9	T15
SVJBR/L2020K16	20	20	125	32	20	25			
SVJBR/L2525M16	25	25	150	40	25	32			
SVJBR/L3232P16	32	32	170	45	32	40			

Обозначение	Размеры						Пластина	 Винт	 Ключ
	H	W	L	l	h	s			
SVJBR/L1010H11F	10	10	100	10,5	10	10	VB**1103	M2.5*8	T8
SVJBR/L1212H11F	12	12	100	12,5	12	12			
SVJBR/L1616K11F	16	16	125	16,5	16	16			

# SVJBR/L



Обозначение	Размеры							Пластина	 Винт	 Ключ
	d <sub>min</sub>	Ø d	S	L	ℓ	H	α°			
S10K-SVJBR/L11	Ø11	10	6	125	28	9	13°	VB**1103	M2.5*6	T8
S12M-SVJBR/L11	Ø14	12	7	150	35	11	10°			
S16Q-SVJBR/L11	Ø18	16	9,5	180	40	15	10°		M2.5*8	
S20Q-SVJBR/L11	Ø22	20	11,5	180	45	18	8°			
S16Q-SVJBR/L16	Ø22	16	11,5	180	45	15	14°	VB**1604	M3.5*9	T15
S20Q-SVJBR/L16	Ø22	20	11,5	180	48	18	11°			
S25R-SVJBR/L16	Ø27	25	14	200	54	23	9°			

Обозначение	Размеры									Пластина	Std corner R3(r)	 Винт	 Ключ
	d <sub>min</sub>	ФD	H	L1	L2	L3	L4	F	α°				
S12M-SVJBR/L08-AV	Ø16	12	11	150	26	33	21	2	5°	VB**0802	0,2	T6	M2*5
S20R-SVJBR/L11-AV	Ø25	20	19	200	37,5	48	30	2	8°	VB**1103	0,4	T8	M2.5*8
S25S-SVJBR/L11-AV	Ø30	25	23	250	45	58	33	3,5	5°				
S32S-SVJBR/L16-AV	Ø35	32	30	250	60	74	45	18	8°	VB**1604		T15	M3.5*9
S40S-SVJBR/L16-AV	Ø50	40	38	250	75	91	49	4,5	7°				