



## SVJCR/L







Обозначение	Размеры						Пластина	 Винт	 Ключ
	H	W	L	l	h	s			
SVJCR/L1212F11	12	12	80	22	12	16	VC**1103	M2.5*8	T8
SVJCR/L1616H11	16	16	100	25	16	20			
SVJCR/L2020K11	20	20	125	32	20	25			
SVJCR/L2525M11	25	25	150	38	25	32			
SVJCR/L1616H16	16	16	100	30	16	20	VC**1604	M3.5*9	T15
SVJCR/L2020K16	20	20	125	32	20	25			
SVJCR/L2525M16	25	25	150	40	25	32			
SVJCR/L3232P16	32	32	170	45	32	40			

Обозначение	Размеры						Пластина	 Винт	 Ключ
	H	W	L	l	h	s			
SVJCR/L1010H11F	10	10	100	10,5	10	10	VC**1103	M2.5*8	T8
SVJCR/L1212H11F	12	12	100	12,5	12	12			
SVJCR/L1616K11F	16	16	125	16,5	16	16			

# SVJCR/L



Обозначение	Размеры							Пластина	 Винт	 Ключ
	dmin	ø d	S	L	ℓ	H	a°			
S10K-SVJCR/L11	Ø12	10	6	125	28	9	13°	VC**1103	M2.5*6	T8
S12M-SVJCR/L11	Ø14	12	7	150	35	11	10°			
S16Q-SVJCR/L11	Ø18	16	9,5	180	40	15	10°			
S20Q-SVJCR/L11	Ø22	20	11,5	180	45	18	8°			
S16Q-SVJCR/L16	Ø18	16	9,5	180	45	15	12°	VC**1604	M3.5*9	T15
S20Q-SVJCR/L16	Ø22	20	11,5	180	48	18	10°			
S25R-SVJCR/L16	Ø27	25	14	200	54	23	7°			

Обозначение	Размеры									Пластина	Std corner R3(r)	 Винт	 Ключ
	dmin	ФD	H	L1	L2	L3	L4	F	a°				
S12M-SVJCR/L08	Ø14	12	11	150	26	33	20	7	9°	VC**0802	0,4	T6	M2*5
S16Q-SVJCR/L08-AV	Ø18	16	15	180	36	43	22	9,5	10°				